



altro

Terminating Altro Whiterock™ above a drop ceiling grid

Altro Whiterock installed over drywall using AltroFix W39 adhesive and continuing through drop ceiling grid level.

When this installation occurs the ceiling grid must be installed to allow for expansion and contraction of the wall panel.

This can be achieved by first making a pilot hole slightly larger than the fastener through the panel and then fastening the ceiling grid to the substrate.

