



altro

PREFERRED METHOD

Floor to wall overlap transition

An overlap transition from floor to wall is our preferred installation method and is utilized in most installations. It is completed by installing the flooring 6" – 8" up the wall, dependent on cove size and installing the Altro Whiterock with a 2" overlap. The juncture is then finished with Altro sanitary sealant.

This installation technique is easier to install versus a heat-welded transition and offers enhanced security over water ingress.

