



altro

Adhering directly to the ceiling using two part joint strip method

Altro Whiterock installed on smooth ceiling substrates with Altro W39 two-part polyurethane adhesive and 2" double faced tape.

Cover back of panel with a placement as shown in diagram. Fill in the empty space with appropriate Altro W39 two-part polyurethane adhesive. You may need to support the panels until the adhesive sets. Apply Altro W165 tape adhesion promoter to ceiling to match tape pattern of panel. Follow appropriate instructions for two-part joint strip installation.

