

## Installation tools for transport



1  
Heat welding kit  
AST HWKTF



2  
Heat welding gun  
AST HWG




3  
Heat welding nozzle  
AST HWNT




4  
4mm heat welding tip  
AST HWT4MM



5  
Welding tip for HB weld  
AST HWT4HB



6  
Heat welding tip cleaning brush  
AST HWCBB



7  
Feed roller for HB welding  
AST FRHB



8  
Trimming knife straight handle  
AST TKSH




9  
Metal trim plate  
AST TP



10  
Grooving tool handle  
AST GH



11  
Grooving tool blade  
AST GBS




12  
Speed groover  
AST GSPEED


Tools (continued)



13  
Bend handle groover  
AST GHB




14  
Groover blade "U" shape (10 pc)  
AST GBU



15  
Xacto Handle  
AST XH



16  
Xacto blades (8 pc)  
AST XB8



17  
Straight blades (100 pc)  
AST BS



18  
Hooked blades (100 pc)  
AST BH




19  
Concave blades (100 pc)  
AST BC




20  
2" seam roller  
AST RSH



21  
3 section floor roller  
AST R3



22  
Trowel blade 1/32 x 1/16 x 5/64 U  
AST TBWHA



23  
Trowel blade 1/32 x 1/16 x 1/32 U  
AST TBFFA



24  
Trowel handle  
AST TH



25  
Electric groover  
AST GE



26  
Electric groover diamond blade  
AST GEDB