the future is safer with altro

Altro floor cleaner

AltroClean 44[™]

February 2015

Part No. FC445L/FC441L

Keep out of reach of children. Avoid contact with skin and eyes.

AltroClean 44 is specially formulated to clean Altro safety flooring in kitchens and other areas where removal of grease and cleanliness of floors is essential. It can also be used for removing old or worn coatings of seals / polishes from Altro rubber flooring and Altro smooth vinyl flooring.

Method of use

- 1. Sweep the floor.
- 2. Add AltroClean 44 to clean, warm water; the dilution rate depends upon the degree of soiling (see below).
- 3. Apply with suitable equipment such as a deck scrubber or similar, preferably a machine fitted with medium or heavy duty pads (brushes for Altro Marine 20) and leave for several minutes for the cleaner to attack the surface soil.
- 4. Rinse the floor with clean water and dry after use.

Dilution rate

Regular maintenance: use 1 part AltroClean 44 to 40 parts clean, warm water. For heavily soiled floors: use 1 part AltroClean 44 to 10 parts clean, warm water. To remove emulsion based seals: use 1 part AltroClean 44 to 5-10 parts clean, warm water, depending on the seal used.

General

Full maintenance details for the range of Altro floors are available from Altro.

Health and safety precautions

Keep containers closed and away from children. This is an alkaline cleaner. As with all alkaline cleaners prolonged skin contact should be avoided. Wear rubber gloves.

First aid

Skin: The affected area should be irrigated with water and washed with soap.

Eyes: In case of contact with eyes irrigate with copious amounts of water. Seek medical attention.

Ingestion: Do not induce vomiting. Give drinks of milk or water and seek medical attention immediately.

Spillages

Flush thoroughly with water. Available in 1 litre and 5 litres.

If you'd like any more information or guidance please get in touch, we're here to help.

tel: 01462 707600 fax: 01462 707515

email: enquiries@altro.com or explore www.altro.com