

NBS M50 ALTRO ORCHESTRA CUSTOM SMOOTH VINYL FLOORING COMBINED PARAGRAPHS.

TYPE(S) OF COVERING

150 PLASTICS FLOORING:

- Location:
- Base:
- Preparation: Clauses
- Fabricated underlay: _____ as clause _____
- Flooring roll: Heterogeneous PVC to BS EN 651.
Manufacturer and product reference: **Altro Orchestra 2.85 mm thick Smooth Floor by Altro Floors**, telephone 01462 480480, fax 01462 480010.
BS EN 685 class 34/42.
Width: **2000mm**
Thickness: **2.85mm**
Colour: **TBC**
- Adhesive (and primer if recommended by manufacturer):
- Seam welding: Hot-welding with matching Altro Welding Rod, as clause 680A.
- Accessories: Clauses
- Skirting: Clauses
- Maintenance and Finishing: Clauses
- Special requirements: Where the flooring is used to form the coved skirting, make certain that the wall background is smooth, clean and dry enough to allow full adhesion of the system.

This specification, in whatever format - electronic, is only valid if it is a true copy of the filed paper copy held at Altro. If you are in any doubt as to the authenticity of the copy, please ask for verification.

GENERALLY

210 WORKMANSHIP GENERALLY:

- All bases must be rigid, dry, sound, smooth and free from grease, dirt and other contaminants before coverings are applied.
- Finished coverings must be accurately fitted, tightly jointed, securely bonded, smooth and free from air bubbles, rippling, adhesive marks and stains.

220 SAMPLES:

Before placing orders, submit for approval a representative sample of each type of covering. Ensure that delivered materials match samples.

230 CONTROL SAMPLE(S):

Complete area(s) of the finished work in approved location(s) as follows, and obtain approval of appearance before proceeding:

250 LAYOUT:

Agree setting out of seams before ordering roll materials for sheeting type(s) M50/150.

251 LAYOUT:

Set out sheet coverings so that seams and cross seams are kept to a minimum. Cross seams will not be permitted.

252 LAYOUT:

Agree setting out of pattern before ordering materials for covering type(s) M50/150.

- 270 **EXTRA MATERIAL:**
Provide **5%** extra of each type of covering to be handed over to the Employer at completion.
- 310 **MARKING:**
Ensure that materials are delivered to site in original packing, clearly marked with batch number.
- 320 **STORAGE:**
Store materials in a clean, warm, dry, well ventilated place. Keep in original packing until conditioning commences.
- 330 **COMMENCEMENT:**
Do not lay materials until building is weathertight, wet trades have finished their work, the building is well dried out, all paintwork is finished and dry, conflicting overhead work completed, and floor service outlets, duct covers and other fixtures around which the materials are to be cut have been fixed. Inform CA not less than 48 hours before commencing laying.
- 340 **CONDITIONING:**
Before laying commences thoroughly condition materials by unpacking and separating in the spaces where they are to be laid. Maintain resilient flooring rolls in an upright position, unroll carpet and keep flat on a supporting surface. Minimum conditioning time and temperature to be as recommended by manufacturer. Extend period by a factor of 2 for materials stored or transported at a temperature of less than 10°C immediately prior to laying.
- 350 **ENVIRONMENT:**
Before, during and after laying, provide adequate ventilation and maintain temperature and humidity approximately at levels which will prevail after the building is occupied.
- 360 **UNDERFLOOR HEATING:**
In accordance with BS8203 Underfloor heating should be switched off 48 hours prior to laying the floorcovering. The heating should not be turned on until at least 48 hours after laying and peak temperature should be avoided for a further 7 days.

PREPARING BASES

- 410 **SUITABILITY OF NEW BASES AND CONDITIONS:**
Laying of coverings will be taken as joint acceptance by the Main Contractor and Subcontractor of the suitability of the bases and conditions within any given area.
- 420 **SUITABILITY OF EXISTING BASES AND CONDITIONS:**
- Before commencing work the subcontractor must confirm (through the Main Contractor) that existing bases will, after the specified preparation, be suitable to receive the specified coverings.
 - Laying of coverings will be taken as further acceptance of the suitability of the bases and also of the conditions within any given area.
- 430 **DAMPNESS:**
Where coverings are to be laid on new wet-laid bases:
- Ensure that drying aids have been turned off for not less than 4 days, then
 - Test for moisture content using an accurately calibrated hygrometer in accordance with BS 5325, Annexe A or BS 8203, Annexe A.
 - Take readings in all corners, along edges, and at various points over the area being tested.
 - Do not lay coverings until all readings show 75% relative humidity or less.
- 440 **SUBSTRATES:**
The specifications for trowelled finishes to receive thin floor coverings require:
- A uniform, smooth surface free from trowel marks and other blemishes, and suitable to receive the specified floor finish material.
 - Adequate protection from construction traffic.

- Allowance for making good by application of a smoothing compound by and to the satisfaction of the flooring subcontractor in the event of the surface being unsuitable due to inadequate finishing or protection.
- 462A SMOOTHING UNDERLAYMENT COMPOUND:
- Manufacturer and reference: **Ardex UK Ltd, ArditeX 'NA' smoothing compound.**
 - Apply to base at a minimum thickness of 3mm in accordance with manufacturer's product data sheet incorporating aggregate for applications more than 12mm thick.
 - Allow to dry before laying floor tiling/sheeting.
- 470 EXISTING FLOOR COVERING TO BE REMOVED:
Completely remove covering and as much adhesive as possible. Skim with smoothing underlayment compound to give a smooth, even surface.
- 480 EXISTING FLOOR COVERING TO BE OVERLAID:
Make good by local resticking and patching or filling with smoothing underlayment compound to give a smooth, even surface.
- 531A SURFACE DAMP PROOF MEMBRANE:
- Manufacturer and reference: **AltroProof epoxy surface damp proof membrane by Altro Floors effective up to 97% R.H.**
NB: Please note AltroProof 'Fast Track' is also available where floor coverings are to be laid same day. Conditions apply.
 - In the event of underfloor heating please consult Altro Technical for conditions of use.
 - Apply in accordance with manufacturer's instructions.
- 560 PLYWOOD UNDERLAY:
- To an approved national standard.
Bonding quality to BS EN 314: Part 2: Class 3
Finish: _____
Thickness: _____ mm.
Sheet size: _____ x _____ mm.
 - Ensure that existing floor boards are securely fixed and acceptably level. Remove or fill any gross irregularities. Punch in any protruding fasteners.
 - Lay sheets with cross joints staggered such that no joint within the base and underlay is coincident and with a 0.5-1 mm gap between sheets.
 - Fix with 25 mm ring shanked or twisted shank nails or divergent staples, commencing at the centre of one side of each sheet, at 150 mm grid centres over the area of each sheet and at 100 mm centres along perimeter, set in 12 mm from edge.
 - Ensure that fasteners are driven well in, with heads set flush with surface, and do not project through underside of base. Remove and replace fasteners that deform while being driven.

LAYING COVERINGS

- 620 COLOUR CONSISTENCY:
In any one area/room use only coverings from the same production batch to prevent banding or patchiness resulting from colour/flash variation.
- 640 ADHESIVE FIXING GENERALLY:
- Adhesive: when not specified otherwise, type to be as recommended by covering/underlay manufacturer as appropriate or, in the absence of such recommendation, type to be approved.
 - Use a primer where recommended by adhesive manufacturer. Allow to dry thoroughly before applying adhesive.
 - Spread adhesive evenly and lay covering, pressing down firmly and rolling laterally and transversely (if recommended) to ensure full contact and a good bond overall. Reroll (if recommended) within 30 minutes.
 - Remove all surplus adhesive from exposed faces of coverings as the work proceeds.
 - Trowel ridges and high spots caused by particles on the substrate will not be accepted.

- 641A ADHESIVE FIXING – ALTRO SHEET FLOORING:
- Place the material in position on the floor, allowing at least 25 mm each end for trimming, and overlapping at least 15 mm at joints.
 - Cut-in material along joints.
 - Fold (do not roll) the material back along half its length. When adhesive is ready, refold material back onto adhesive. Repeat for second half of material.
 - Consult data sheet on rolling requirements..
- 670 BORDERS/FEATURE STRIPS of sheet material:
- Cut strips along the length of the sheet to prevent curl.
 - Mitre joints at corners.
- 680A SEAM WELDING:
- Do not commence welding of coverings until a minimum of 24 hours after laying or until adhesive has completely set.
 - Cut groove, 3 mm wide by $\frac{2}{3}$ the depth of material, evenly along each joint using:
 - Altro hand grooving tool or
 - Automatic grooving machine fitted with diamond blade.
 - Hot-weld using hot air welding gun (fitted with high speed welding nozzle) and Altro welding rod. Select colour of rod to match floor covering. Cut off surplus weld rod with spatula.
 - Form a neat, smooth, strongly bonded joint, flush with finished surface.
- 680B SEAM WELDING
- Cold Weld compatible. [Optional for flat lay installations only] Please speak to Altro Technical Services for further information.
- 720 DOORWAYS:
- Make joint on centre line of door leaf unless specified otherwise.
- 731A SEALANT:
- Manufacturer and reference: AltroMastic 100 by Altro Floors, colour to match floorcovering.
 - Location: To all exposed edges of flooring material around all protrusions through floor and pipework as necessary.
- 740 EDGINGS/COVER STRIPS:
- Manufacturer and reference(s): Quantum _____
 - Material/finish: Aluminium / PVC.
 - Fix securely in accordance with manufacturers instructions.
- 741A EDGING TO _____
- Manufacturer and reference: Visedge VR Edge Strip by Howe Green Ltd.
 - Size: 9 mm deep x 30 mm wide.
 - Cut recess in base, bed edge strip level in epoxy mortar, and securely screw to base with neatly mitred joints.
 - Make good base by filling with smoothing compound to give a smooth, even surface.
 - Cut, groove and hot weld PVC insert to Altro safety flooring.
 - See Altro detail drawing D12.
- 741B EDGING TO _____
- Use disc cutter to form 25 mm deep x 4 mm wide channel at junction with adjacent floor finish.
 - Manufacturer and reference: Gully Angle GA25/35 by Altro Floors.
 - Size: 25 x 25 mm.
 - Colour: TBC
 - Orientate angle to suit thickness of flooring material. Fix securely and level with neatly mitred joints, bonding to base and to inside of chase using Altrofix 19.
 - Cut, groove and hot weld angle to Altro safety flooring.
 - See Altro detail drawing D10.
- 750A STAIR NOSINGS:
- Manufacturer and reference(s): Altro _____.

Material/finish:

Inserts: Altro safety flooring, colour _____

Adhesive: Laybond Gripfill / Similar Approved.

- Bevelled underlay strips: Quantum.
Lay under adjacent flooring to provide smooth joint with nosing.
- Fix securely and level with neatly mitred joints. Screw fixing with matching plugs _____ required.

751A STAIR TRIM:

- Manufacturer and reference: Altro _____ stairs trim with welded mitre angle by Altro Floors.
Material:
Length of each return leg: 360 mm.
Outer angle between treads and risers: ____
- Fixing: Securely bond with top edge parallel with stair tread. Accurately mitre inner junction of each tread and riser.
Adhesive: Laybond Gripfill / Similar Approved.

751B LANDING TRIM:

- Manufacturer and reference: Altro _____.
- Material:
Fixing: Securely bond with top edge straight and aligned with floor. Accurately mitre at corners.
Adhesive: Laybond Gripfill / Similar Approved.

760 STAIR COVERINGS:

Neatly cut and tightly fit risers first, then treads.

761A STAIR COVERINGS:

Fit tread and riser in one piece on stairs with coved tread/riser.

- Cove former: Altro Type 20R.

770A SET-IN COVED SKIRTINGS:

- Manufacturer and reference(s): See Quantum
Size: 100mm high x 25mm wide at base.
Colour: Black 208 / Dove 001 / White WHT
- Securely bond with top edge straight and parallel with floor. Accurately mitre at corners.
- Hot weld to edge of floor with matching Altro Welding Rod. Do not chemical weld.
- Seal mitred corners using AltroMastic 100.
 - See Altro detail drawing D3.

770B SIT-ON COVED SKIRTINGS:

- Manufacturer and reference(s) Quantum.
Size: 100 mm high x 19 mm wide at base.
Colour: TBA
- Seal between wall and floor perimeter with AltroMastic 100, prior to fixing skirting.
- Securely bond with top edge straight and parallel with floor. Accurately mitre at corners.
 - See Altro detail drawing D2.

771A SELF-COVED SKIRTINGS - GENERAL:

- Cove former: Altro 38R.
Securely bond to base and background.
- Turn flooring material up wall and securely bond to cove former and background, with top edge straight.
Accurately mitre at corners.
Height: Minimum 100mm
Top edge: Altro: C7 Capping Seal / C8 Captile Strip / C11 Quarry Tile Seal
- Hot weld joints and mitred corners with matching Altro welding rod. Do not chemical weld.
 - See Altro detail D4 (C7) / D5 (C8) D6 (C11)

771B SELF-COVERED SKIRTINGS - WHITEROCK:

- Cove former: Altro 38R.
Securely bond to base and background.
- Turn flooring material up wall and securely bond to cove former and background, with top edge straight.
Accurately mitre at corners.
Height: Minimum 150mm
Top edge: Overlap by 50mm
- Hot weld joints and mitred corners with matching Altro welding rod. Do not chemical weld.
- Seal underside of Whiterock sheet using AltroMastic 100 clear.
 - See Altro detail drawing WF8

773A JUNCTIONS BETWEEN SELF-COVERED SKIRTINGS AND DOOR FRAMES/ARCHITRAVES:

Trim back of cove formers in proximity to door openings, and terminate self-coved skirtings against side of architraves.

- See Altro detail drawing D9.

775A STAIR STRINGER:

- Manufacturer and reference: Altro _____ by Altro Floors.
Thickness: _____ mm
Colour: _____
- Accurately cut to profile of tread and riser. Securely bond to background with top edge straight and parallel to pitch of stairs.
Height: _____ mm, measured normal to stair pitch, from inner junction between tread and riser.
Top edge: _____
- Seam welding to treads/risers: Hot-welding with matching Altro welding rod.

780A TRAFFIC:

After laying, keep floor covering free from traffic until adhesive is set.

COMPLETION

810 CLEANING GENERALLY:

Remove all scrap, dust and dirt. Carefully remove adhesive and other marks from coverings and adjacent surfaces, using approved cleaning agents and methods.

821A FINISHING PLASTICS FLOORING:

GENERAL

- Use AltroClean 48W cleaner/maintainer or equivalent and mop wash or spray clean with soft pads after initial clean.
 - Contact Altro for detailed cleaning instructions: Altro Limited, tel: +44(0)1462 707600, fax: +44 (0)1462 707515, email: enquiries@altro.com

870 PROTECTION:

Cover flooring with clean dust sheets, or other nonstaining suitable material to prevent damage from dirt and traffic prior to Practical Completion. Ensure any material with printed information on one face is laid with printed face uppermost.