



altro

Installation instructions for Altro Lavencia™

updated 07/22/19

Materials

Altro Lavencia is suitable for all interior floor surfaces, above, on or below grade, and over concrete or wood substrates. With a clear wear layer of 22mil, Altro Lavencia is ideally suited for commercial environments such as retail, leisure, health and education.

Altro Lavencia is manufactured under ISO 9001:2008, Quality management systems and ISO 14001 Environmental Management System. It is completely recyclable, contains recycled content and is suitable for use with under-floor heating.

Conditions and requirements

- Concrete floors shall be constructed in accordance with the American Concrete Institute (ACI) 302.1R-04 Guide for Concrete Floor and Slab Construction and ACI 302.2R-06 Guide for Concrete Slabs that Receive Moisture Sensitive Flooring Materials. Please consult www.concrete.org for the most current editions of ACI's.
- Floors must be finished and cured according to ACI with a minimum compressive strength of 3500 psi.
- Floors must be clean, dry and smooth. Any surface materials, such as paint, wax, grease, oil, adhesive residues, etc. must be mechanically removed.
- Floors must be free of any sealers, curing, hardening or parting compounds that would adversely affect the adhesive used with the flooring.
- A moisture barrier shall be installed prior to pouring of on or below grade slabs. All on-grade and below-grade concrete slabs regardless of the concrete's age must have an effective moisture vapor barrier/retarder present under them; if a fully intact non-damaged vapor retarder cannot be confirmed then the concrete must be treated as if it will get wet from ground moisture at a future time.
- When a sub-slab vapor barrier/retarder cannot be confirmed it is required to install a surface applied moisture barrier system.

Moisture reduction barriers

While Altro does not approve any specific MRBs we do recognize the need for them in certain circumstances.

There are no known incompatibility issues with Altro floor coverings, their adhesives, and the many types of moisture reduction barriers available, however final determination of a particular product's suitability and its warranties as regards to the performance of the moisture reduction system and/or any damage that may be caused to the Altro floor coverings and their adhesives due to deficiencies in the moisture reduction system are the responsibility of the moisture reduction system, manufacturer, and installer.

- Always conduct moisture tests per ASTM F-2170 on all concrete slabs regardless of age or grade level. ASTM F-2170 relative humidity (RH) test results must not exceed 90% when using EcoFix 25E or 95% when using EcoFix 65 Spray. As a general rule, a 4" thick slab will require a minimum 3-month drying time before performing moisture tests.
- Concrete surface pH must be tested in several locations and be below a pH of 9.9.
- Wood floors must be double layer construction with a minimum thickness of 1". The top layer shall be APA Underlayment Grade Plywood or other wood underlayment panel approved and warranted beneath resilient flooring. Consult with the underlayment manufacturer for specific recommendations and warranties.
- Maintain room temperature, adhesive and flooring material at 68° F – 80° F (20C – 26C) for 72 hours before, during and after installation.

Preparation

- The existing subfloor should be mechanically abraded to remove any paint, wax, grease, oil, plaster, sealers, curing compounds and other foreign materials that may be present from the construction process.
- A thorough vacuuming should be done to ensure a dust free substrate.
- Remove all subfloor ridges and bumps.

- Fill low spots, cracks, control joints and other defects with a Portland based latex underlayment material. Follow all manufacturers mixing and application instructions.
- High spots may need to be ground down to ensure a surface flatness of 3/16" in 10 ft. Always allow patching material to dry/cure completely before installing the Altro Resilient Floor Tile.
- For proper removal of existing flooring and adhesives refer to the Resilient Floor Covering Institute guidelines.

Adhesives

Altro Lavencia may be installed using either our pressure sensitive acrylic adhesive EcoFix 25E or our fast acting EcoFix 65 Spray adhesive. Follow the installation instructions below.

Using EcoFix 25E adhesive

- ASTM F-2170 relative humidity (RH) test results must not exceed 90%.
- Use EcoFix 25E adhesive wherever possible, allow the adhesive to dry to a pressure sensitive state before installing tile. When a wet set, hard set adhesive is needed use EcoFix 20E hard set acrylic adhesive.
- Apply adhesive with a 1/32" deep x 1/16" wide x 1/32" notched trowel.
- Allow adhesive ample open time* to "gas off" and tack-up before proceeding to install tile. Installation too late in the pressure sensitive stage of the adhesive reduces the strength of the bond and can cause the lines of the adhesive to show through to the surface of the flooring.
- Flooring must be rolled in its entirety with a 100 lb. roller.
- The adhesive open time, working time, set and curing time will depend on the type of substrate, its absorbency, the temperature and the and the air humidity in the premises.
- Prohibit heavy traffic and pallet jack type rolling loads on floor tile for 72 hours after installation.

Using EcoFix 65 Spray adhesive

- Before use, be sure to shake can of EcoFix 65 Spray well.
- Spray from a standing position, holding can 20-30 inches (50-70cm) from floor.
- Protect walls from overspray with a spray shield of a piece of cardboard.
- Allow adhesive to dry to the touch. Test this by lightly touching the adhesive - there should be no adhesive transfer to your fingers. Too much adhesive or high humidity will increase dry time.
- Open working time after tack is 4 hours.
- Roll floor immediately with a 75-100 lb. roller.
- Floor is open to all traffic immediately after installation.
- Clean up with a damp cloth for wet overspray.
- Use mineral spirits for dry overspray.

Layout

- In laying out commercial installations (large open areas, hallways, etc.), the use of a transit or laser is recommended to strike guidelines.
- The lines should be positioned so that product will be used economically, with as little waste as possible.
- Installations in long hallways with adjoining rooms should be carefully planned to provide for one half the tile width along walls and in the doorways, if possible.
- In smaller rooms, where all border areas are plainly visible, care should be taken so that border tiles are uniform in width and as large as possible.

Laying plank/tile

- Altro Lavencia installed next to each other shall be in consecutive lot numbers.
- Position the tile at proper position in the adhesive without sliding and press firmly down, paying special attention to the tile edges and corners and that the ends of the planks are staggered for best visual appearance.
- Periodically check by lifting a tile to make sure that at least 95% of the adhesive pattern has been transferred to the back of the tile.
- Roll each section in both directions immediately upon completing with a minimum 100 lb. three section roller or a hand roller in smaller areas. Re-roll the entire area after one or two hours.
- Promptly remove adhesive smudges with a clean cloth dampened with soap and water while the adhesive is still fresh and gentle mineral spirits when dried. Be sure to test strength of mineral spirits before use to avoid damage to tiles.

Protection

- Equip all heavy furniture, appliances and carts with soft, non-staining casters or rests of sufficient size to meet static load resistance requirements.
- Use plywood panels to protect flooring from damage that may occur when moving heavy objects over flooring.
- Protect the floor covering installation against dirt and other trades.
- Do not damp mop or polish the floor for a minimum of 48 hours after installation.
- Do not wash thoroughly before 30 days. Wipe with a damp mop during the first month to allow adhesive to cure.
- Temperature and humidity during and after the floor covering installation will have a direct effect on the drying time of the adhesive, therefore ensure that room temperature is kept at a minimum of 68°F (15°C) and relative humidity is no more than 65% for a period of 72 hours after the completion of work.
- The manufacturer or supplier will not be liable for any loss, damage or complaint of any kind if the specific laying procedure described in this guide is not followed. Neutralize any traces of strong acid or alkali prior to application of the surface preparation product or the adhesive.