



### NBS M50 ALTRO WHITEROCK VANTAGE™ WALL CLADDING

#### TYPE(S) OF COVERING

##### 110 PVCu LININGS TO WALLS:

- Project:
- Location:
- Substrate:
- Preparation:
- Sheet: Co-extruded PVCu sheet,
- Maximum service temp: 60°C
- Fire rating: EN13501-1 B-s3, d0
- Manufacturer / Product reference:
  - **Altro Whiterock™ Vantage W107/W108** wall cladding by Altro Limited, Telephone +44(0)1462 707600, email enquiries@altro.com
- Length: 1220 mm
- Width: 2500mm (W107), 2750mm (W103/2750) 3000mm (W108)
- Thickness: 2.5 mm
- Surface finish: Satin
- Colour: various
- Light reflectance values: 81
- Adhesive: **AltroFix™ W139**
- Joints:
- Accessories:
- Maintenance and finishing:
- Special requirements:

**This specification, in whatever format, is only valid if it is a true copy of the filed paper copy held by Altro. If you are in any doubt as to the authenticity of the copy you hold, please ask for verification.**

#### GENERALLY

##### 210 WORKMANSHIP GENERALLY:

- All bases must be rigid, dry, sound, smooth and free from grease, dirt and other contaminants before coverings are applied.
- Finished coverings must be accurately fitted, jointed as per manufacturer's instructions, securely bonded, smooth and free from air bubbles, rippling, adhesive marks and stains.

##### 220 SAMPLES:

- Before placing orders, submit for approval a representative sample of each type of covering. Ensure that delivered materials match samples.

##### 230 CONTROL SAMPLE(S):

- Complete area(s) of the finished work in approved location(s) as follows, and obtain approval of appearance before proceeding:

---

---

---

##### 251 LAYOUT:

- Set out sheet coverings so that joints are kept to a minimum.  
Internal and external corners to be thermoformed onsite, limiting the number of joints required.

##### 310 MARKING:

This specification, in whatever format, is only valid if it is a true copy of the filed paper copy held by Altro. If you are in any doubt as to the authenticity of the copy you hold, please ask for verification.

- Ensure that materials are delivered to site in original packing, clearly marked with batch number.
- 320 STORAGE:
- Store materials in a clean, warm, dry, well-ventilated place (14°C – 27°C) and must not be stored outside in direct sunlight as distortion can occur. Keep in original packing until conditioning commences.
- 330 COMMENCEMENT:
- Do not lay materials until building is weather tight, wet trades have finished their work, the building is well dried out, all paintwork is finished and dry, conflicting overhead work completed, and service outlets, duct covers and other fixtures around which the materials are to be cut have been fixed. Inform CA not less than 48 hours before commencing fitting.
- 340 CONDITIONING:
- Sheets should be stored flat, fully supported and left for 24 hours to attain the ambient room temperature prior to installation (recommended 18°C). Minimum conditioning time to be increased by a factor of 2 for materials stored or transported at a temperature of less than 10°C immediately prior to installing.
- 350 ENVIRONMENT:
- GENERAL**
- Before during and after laying, provide adequate ventilation and maintain temperature and humidity approximately at levels which will prevail after the building is being occupied.
- 350A ENVIRONMENT:
- HEAT**
- Areas where open cooking or open flame equipment is being used should comply with the following:
  - Altro PVCu wall sheets have a maximum working temperature of 60°C and once installed should not be exposed to temperatures above this. For areas that exceed these maximum temperatures, such as direct heat sources or where there is exposure to naked flames (examples being air fryers, heat vents, cookers, oven ranges, wall-mounted griddles etc.) it is recommended that stainless-steel sheets are used. Where installations of stainless-steel sheets are to be included, the stainless steel must extend at least 300mm beyond the heat source to ensure protection of these localised areas is maintained. If a layout drawing highlighting areas where heat may be of concern can be provided, specific advice can be provided as to the best combination of materials to use.
  - Before the testing of Kitchen equipment which is likely to expel severe heat, extraction systems must be operational. Failure to do so may result in expansion problems.
  - With the construction of a dry wall system in a kitchen area or where the area has been adapted to form a wall behind cooking ranges. Altro Walls recommends the substrate or dry wall lining should be constructed with a Calcium Silica board. Stainless steel panels should then be used to clad these areas.
  - Hot pipes and steam pipes should be insulated and a 3-5mm expansion gap should be created when installing panels around these pipes.

### PREPARING SUBSTRATES

- 410 SUITABILITY OF NEW SUBSTRATES AND CONDITIONS:
- Fitting of coverings will be taken as joint acceptance by the Main Contractor and Subcontractor of the suitability of the substrates and conditions within any given area.
- 420 SUITABILITY OF EXISTING SUBSTRATES AND CONDITIONS:
- Before commencing work the subcontractor must confirm (through the Main Contractor) that existing substrates will, after the specified preparation, be suitable to receive the specified coverings.
  - Fitting of coverings will be taken as further acceptance of the suitability of the bases and also of the conditions within any given area.

This specification, in whatever format, is only valid if it is a true copy of the filed paper copy held by Altro. If you are in any doubt as to the authenticity of the copy you hold, please ask for verification.

- 430 DAMPNESS:
- Where linings are to be fitted on new wet-laid substrates:
  - All substrates to be dried to minimum of 16% WME (Wood Moisture Equivalent) on Protometer 'Survey master' equipment or similar.
  - Take readings in all corners, along edges, and at various points over the area being tested.
- 440 SUITABLE SUBSTRATES: GENERAL
- The specifications for finishes to receive PVCu wall cladding require:
  - Good quality fair faced brick or blockwork. Well aligned joints bagged up flush. Straight to within 3mm over a 2m straight edge and bricks/blocks flush with one's adjacent.
  - Sand & cement rendering 1:3 to steel trowel finish.
  - 12.5mm thick plasterboard. (do not seal with sealers as for decorating). If wall is affords fire protection ensure joints between plasterboard sheets filled with appropriate fillers.
  - **Minimum 9mm W.B.P. resin bonded plywood fixed at 200mm centres to suitable studwork or direct to solid substrate.**
  - Minimum 9mm MDF dense wood based panels fixed at 200mm centres to suitable studwork, or direct to solid substrate.
  - Ceramic tiles which are clean and securely bonded to substrate.
  - Certain sound painted surfaces (an adhesive test is advisable to ascertain compatibility).
  - Plastered surfaces - finished with steel trowel. (pink lightweight plasters generally not suitable).
  - Porous surfaces to be thoroughly sealed with diluted PVA applied to the surface 12 hours prior to the installation. The sealer should be used in a diluted ratio of 1:10. Alternatively use **Altro Primer Seal** Ref: AGCPNF/01
- 440A SUITABLE SUBSTRATES - WELDED FINISH:
- Surface straight to within 3mm over a 2m straight edge.
  - Sand & cement rendering 1:3 to steel trowel finish.
  - 12.5mm thick plasterboard. (do not seal with sealers as for decorating). If wall is affords fire protection ensure joints between plasterboard sheets filled with appropriate fillers.
  - Minimum 9mm W.B.P. resin bonded plywood fixed at 200mm centres to suitable studwork or direct to solid substrate.
  - Minimum 9mm MDF dense wood based panels fixed at 200mm centres to suitable studwork or direct to solid substrate.
  - Ceramic tiles which are securely bonded to the substrate and are level and true without any undulations or raised edges.
  - Certain sound painted surfaces (an adhesive test is advisable to ascertain compatibility).
  - Plastered surfaces - finished with steel trowel. (pink lightweight plasters generally not suitable).
  - Porous surfaces to be thoroughly sealed with diluted PVA applied to the surface 12 hours prior to the installation. The sealer should be used in a diluted ratio of 1:10. Alternatively use **Altro Primer Seal** Ref: AGCPNF/01
- 470 SUBSTRATE PREPARATION - EXISTING WALL FINISH TO BE REMOVED:
- All loose paint and dust to be removed.
  - Friable surfaces should be removed or made sound.
  - (Please consult Altro regarding approved sealing treatments)
  - Make good as needed by local patching or filling with a repair mortar or sand and cement with Unibond mix, to give a smooth, even surface.
  - Straight to within 3mm over a 2m straight edge
- 480 EXISTING WALL FINISH TO BE OVERLAID:
- Make good as needed by local patching or filling with a repair mortar or sand and cement with Unibond mix, to give a smooth, even surface.
  - Ceramic tiles should be thoroughly degreased, using suitable degreasing agent and scouring pad, rinsed with clean water and allowed to dry. Tiles should be abraded with diamond disc and all dust removed. Loose tiles should be removed and the area made good using Ardurapid 45 repair mortar or sand and cement with Unibond mix, if drying time permits. Alternatively, suitable thickness WBP plywood, screwed and plugged, (maximum 200mm centres) may be used.

This specification, in whatever format, is only valid if it is a true copy of the filed paper copy held by Altro. If you are in any doubt as to the authenticity of the copy you hold, please ask for verification.

### FITTING COVERINGS

#### 640 ADHESIVE FIXING GENERALLY:

- Adhesive should not be stored at temperatures below 5°C.
- Recommended ambient temperature of 18°C / 57°F for all installation areas.
- Back of sheets to be cleaned.
- Adhesive should be applied with the recommended notched trowel applicable to the adhesive selected.
- Apply firm even pressure with suitable roller to whole surface area of the panel as work proceeds, to ensure adequate adhesive transfer and good overall bond.
- Use Altro double sided tape Ref A815 or A915 (for welded system) as support whilst adhesive cures.

#### 641A ADHESIVE FIXING – BY **ALTROFIX W139**:

- Use **AltroFix W139** (Ref: A814) two-part polyurethane adhesive spread with a 5mm square notched trowel (Ref: A860).
- On application immediately apply sheet to the wall.
- Support the panel on double sided tape (Ref: A815 or A915 or welded system) whilst adhesive cures (approx. 3-5 hours - full cure 24 hours).

#### 641C ADHESIVE FIXING – BY **ALTROFIX W157**:

- NB. This adhesive is only suitable for porous surfaces, for non-porous surfaces refer to AltroFix W139 or
  - Apply **AltroFix W157** (Ref: A818) water based synthetic polymer adhesive to the back of the sheet using a 3mm deep x 5mm wide square notched trowel (Ref: A860/4).
  - On application immediately apply sheet to the wall.
  - Support the panel on double sided tape (Ref: A815 or A915 or welded system) whilst adhesive cures. (can be 24 hours and upwards)
- NB.** On completion, the installation should not be subject to an increase in ambient temperature to more than 30°C until the adhesive is fully cured. Full cure will be dependent on porosity of substrate

#### 680 SEAM WELDING COVERINGS:

- Do not commence welding of coverings until a minimum of 24 hours after fitting or until adhesive has completely set.
- Use Altro double sided tape (Ref: A915) applied to the wall bridging the joint to be welded. Bring the edges of the sheets to be welded together leaving a 1.5mm - 2mm gap between sheets. Hot weld using hot air welding gun and Altro walls welding rod. Clean off flush with sheet face to form a neat, smooth, strongly bonded joint. Recommended tool is Mozart trimming knife.

#### 731 SEALANT:

- Manufacturer and reference: **Altro Sanitary Sealant** (Ref: A802/803/805) contact Altro Limited, telephone +44(0)1462 707600, fax +44 (0)1462 707515, email enquiries@altro.com

#### 740 EDGINGS/COVER STRIPS: **ALTRO PVC JOINT STRIP**

- All joints should be covered with high impact PVCu 'H' joint sections (Ref: A831 two-part joint trim or G831 single part joint trim).
- Internal/external corners: Altro Fortis Titanium to be thermoformed on-site as needed, so limiting the number of joints required.
- Vulnerable external corners are usually over-clad with **Altro Fortis corner protection** or stainless steel corner protectors, to a height of 1200mm.

#### 740A EDGINGS/COVER STRIPS: **ALTRO FLEXIJOINT**

- Double sided tapes (Ref: A815) applied 3mm in from the edge of the panel
- Install the panels with a specific joint gap of 3.4mm (utilising Altro spacer bars).

This specification, in whatever format, is only valid if it is a true copy of the filed paper copy held by Altro. If you are in any doubt as to the authenticity of the copy you hold, please ask for verification.



- Apply a uniform (2mm) bead of AP600 polymer sealant to the substrate within the joint gap.
- Fit Altro Flexi Joint (FJ01) into the joint gap and roll with a small wooden hand roller
  - See Altro Whiterock detail drawing W11.
- Internal/external corners: Altro Fortis Titanium to be thermoformed on-site, so limiting the number of joints required.
- Vulnerable external corners are usually over-clad with **Altro Fortis corner protection** or stainless steel corner protectors, to a height of 1200mm.

### 740B EDGINGS/COVER STRIPS: ALTRO SILICONE JOINT

- Form a flush joint using a 3-4mm bead of **Altro Sanitary Sealant** (Ref: A802/803/805)
- Internal/external corners: **Altro Fortis Titanium** to be thermoformed on-site, so reducing the number of joints needed.
- Vulnerable external corners are usually over-clad with **Altro Fortis corner protection** or stainless steel corner protectors, to a height of 1200mm.

### 740C EDGINGS/COVER STRIPS: ACCESSORIES

- High impact PVCu two-part start and edge trim (Ref: A833)
- High impact PVCu single part heavy duty start and edge trim (Ref: G833).
- White powder coated aluminium 'H' joint sections (Ref: A854)
- White powder coated aluminium start and edge trim (Ref: A853/25).

### 772 TOP EDGE GENERAL

- To fit top edge of Altro Fortis Titanium sheets into FlexiTrim colour tba

### 773 ABUTMENTS: GENERAL

- To window frame, door frames, architraves, ceiling & quarry tile - seal with **Altro Sanitary Sealant** (Ref: A802/803/805) 3-4mm width joint.

### 773A ABUTMENTS: TREATMENT TO SERVICE PREPARATIONS

- All holes to be cut to allow 3-4mm silicone seal around all penetrations. Seal with **Altro Sanitary Sealant** (Ref: A802/803/805).

### 773B ABUTMENTS: PVC FLOORING

- To PVC flooring with coved skirting - joint to be covered with high impact PVCu transition strip (Ref: A832 two-part trim, or G832 single part trim).
  - Ask for Altro Whiterock detail drawing WF2.
- Alternatively use Altro concealed wall/floor transition strip with overlap detail (Ref G835 / 25) mechanically fixed or bonded to the wall with adhesive (Ref AP600).
  - Ask for relevant Altro Whiterock detail drawing

### 773D ABUTMENTS: RESIN FLOORING:

- To resin flooring with coved skirting, close bottom of sheet with single part high impact PVCu trim section (Ref: G834/25)
  - Ask for Altro Whiterock detail drawing WF6.
- Alternatively, close bottom of sheet with high impact PVCu transition strip (Ref: A832 two-part trim, or G832 single part trim) to resin cove upstands.
  - Ask for Altro Whiterock detail drawing WF5
- Alternatively cove resin skirting feather out to nothing overlap by minimum 50mm with **Altro Fortis Titanium** to seal out bottom edge of sheet with Altro clear silicone sealant (Ref A803)

## COMPLETION

### 810 CLEANING GENERALLY:

- Remove all scrap, dust and dirt. Carefully remove adhesive and other marks from coverings and adjacent surfaces, using approved cleaning agents and methods.
- When cleaning the Fortis Titanium surface, the temperature should not exceed 60 degrees Centigrade.

This specification, in whatever format, is only valid if it is a true copy of the filed paper copy held by Altro. If you are in any doubt as to the authenticity of the copy you hold, please ask for verification.



# NBS SPECIFICATION

## Altro Whiterock Vantage

- Do not use cleaning materials of an abrasive nature
  - Contact Altro for detailed cleaning instructions:
    - Telephone: +44(0)1462 707600
    - email : [enquiries@altro.com](mailto:enquiries@altro.com)
    - website : [www.altro.com](http://www.altro.com)
  
- 821 FINISHING PVC WALL CLADDING:
  - Protective film to be removed.
  - Wipe off any marks and dirt
  - Then dry, apply antistatic solution to all surfaces (Ref: A809).
  
- 870 PROTECTION:
  - If required, tape appropriate protective material to sheet ensuring compliance with surface spread of flame, as per Building Regulations.
  
- 880 WASTE RECYCLING: ALTRO RECOWALL<sup>™</sup>
  - Clean, adhesive-free off-cuts to be removed from site and taken to an Altro Recowall collection points for recycling.
    - Contact Altro for further details of this scheme and the Recofloor recycling scheme.
      - Telephone: +44(0)1462 707600
      - email : [enquiries@altro.com](mailto:enquiries@altro.com)
      - website : [www.altro.com](http://www.altro.com)
  
- 

This specification, in whatever format, is only valid if it is a true copy of the filed paper copy held by Altro. If you are in any doubt as to the authenticity of the copy you hold, please ask for verification.